

Accessories

Mouthpiece Patches

Reduce discomfort, and stabilize the embouchure while protecting the mouthpiece.



Ring Key Patch

Ring Key Patches cover the open toneholes of ring key flutes.



Thumbrest Cushions

Provide a more comfortable thumb position for clarinets, oboes, and tenor or bass recorders.



Valve Protectors

Protect the valve casing of trumpets and cornets. Available in black leather or black vinyl.



Valve Trough for Euphonium

Clips on the bottom valve caps of the Euphonium to trap moisture and oil.



Saxophone Neck Straps

Strong black colored straps comfortable on the shoulders and neck, with an easy-to-adjust hook.



The right accessories can make a big difference to your playing comfort and performance. Yamaha accessories are created with the same care and attention we give to the instruments themselves.

Mouthpiece Pouch


By adopting a cushioning material and antibacterial cloth for its inner surface, your mouthpiece can be stored safely and hygienically.

Model	Instrument	Color	Material
TP1	Trumpet, Cornet/1pc		
TP3	Trumpet, Cornet/3pcs		
HR1	French Horn	Black/Blue/Pink	100% NYLON
TB1	Trombone, Euphonium		
BB1	Tuba		



Music Stands

MS-303AL is extremely light (635g / 22.2 oz) and a compact sized music stand which is made of aluminum. Hard cases and soft cases are available.
WA-10 Wide Attachment helps to support oversized music.



Chart

Maintenance Materials

	Piccolos	Flutes	Clarinets	Saxophones	Oboes	Bassoons	Piston Valve Brass	Rotary Valve Brass	Trombones
Brass Soap									
Metal Polish									
Lacquer Polish									
Silver Polish									
Water Spray									
Bore Oil									
Oil Grease Cleaner									
Mouthpiece Cleaner									
Valve Oil (Light, Regular, Vintage)									
Rotor Oil									
Slide Cream, Slide Oil									
Key Oil (Light, Medium, Heavy)									
Rotor Spindle Oil									
Tuning Slide Oil									
Lever Oil									
Slide Grease (Soft, Hard, Gel)									
Cork Grease (Soft, Hard)									
Flexible Cleaner (S, L, Slide)									
Saxophone Neck Brush									
Mouthpiece Brushes (S, L)									
Tone Hole Cleaners									
Bocal Brush/Swab									
Cleaning Rod									
Polishing Gauze (S, L)									
Metal Cloth (M, L)									
Polishing Cloth (S, L)									
Polishing Cloth DX (M, L)									
Silver Cloth (M, L)									
Silicon Cloth (M, L)									
Cleaning Swab									
Monster Swab (SS, AS, TS)									
Cleaning Paper									
Powder Paper									
Mouthpiece Swab (S, M, L)									
Inner Cloth (Piccolo, Flute, Flute Long)									

Accessories

	Piccolos	Flutes	Clarinets	Saxophones	Oboes	Bassoons	Piston Valve Brass	Rotary Valve Brass	Trombones
Mouthpiece Patch									
Ring Key Patch									
Thumbrest Cushion									
Valve Protector									
Saxophone Neck Straps									

All descriptions and specifications are subject to change without notice.

For details please contact:




WA-34R2

201107
Printed in Japan



Accessories & Maintenance Materials



Frequent Maintenance

Metal Cloth, Polishing Cloth, Silver Cloth and/or **Silicon Cloth** should be used to clean the surface of your instrument after every use.




Valve Oil is especially formulated to give piston valves fast smooth action.




Rotor Oil helps prevent corrosion and reduces friction for smooth, rotary valve operation. **Lever Oil** and **Rotor Spindle Oil** ensure a noiseless mechanism.



Slide Grease and **Tuning Slide Oil** create an air-tight seal and prevent sticking of tuning slides.



Polishing Gauze (size L) wrapped around a cleaning rod removes dirt and moisture from trombone slides.



Slide Cream should be applied to the stockings of a trombone's inner slides, then a **Water Spray** used for smooth action and air-tight seal. A few drops of **Slide Oil** should be applied to the inner slides. When the slide movement gets heavy, spray with a **Water Spray**.



Occasional Maintenance

Mouthpiece Brushes clean the interior of brass mouthpieces. **Mouthpiece Cleaner** removes dirt and sanitizes the surface of the mouthpieces.



Polishes restore the luster to instrument finishes; **Lacquer Polish, Silver Polish,** and **Metal Polish** (for nickel-plated or un-plated surfaces).



Tone Hole Cleaners are ideal to clean out the waterkey holes of brass instruments.



Cleaning Rod and **Polishing Gauze** should be used to clean the interiors of slides, valve casings, and other straight tubing. **Oil Grease Cleaner** removes excess oil which can trap dirt.



Flexible Cleaners have a brush on the end of plastic coated flexible wire for cleaning hard-to-reach tubing and crooks. **Brass Soap** is a neutral detergent specifically developed for cleaning inside brass instruments.



Cleaning Swab and **Mouthpiece Swab** should be used to remove dirt and moisture from inside the instruments, slide and mouthpieces.




Frequent Maintenance

Polishing Gauze, Polishing/Silicon/Silver/Metal Cloth should be used to clean the surface of your instrument after every use.




Cork Grease facilitates attaching joints, prolongs cork life, and maintains air seal. It comes available in both hard and soft types.



Swathed in **Polishing Gauze, Inner Cloth, Cleaning Rods** remove dirt and moisture from the inside of flutes and piccolos. They have a depth mark for visual headjoint adjustment.




Long Type Cleaning Rod can be used without disassembling the flute. It comes with a long type cloth.



Cleaning Swab, Bocal Swab and **Monster Swab** should be used to remove dirt and moisture from inside the instrument after every use.




Cleaning Paper lengthens the life of pads by removing any oil, dirt, and moisture. **Powder Paper** (applied after using **Cleaning Paper**) helps maintain smooth action and prevents sticking.



Occasional Maintenance

Tone Hole Cleaners are ideal for cleaning the insides of toneholes and cleaning difficult to reach areas between the key mechanisms.



Polish restores the luster to instrument finishes. **Lacquer Polish, Silver Polish,** or **Metal Polish** (for nickel-plated or un-plated surfaces) should be applied with **Polishing Gauze**.



A **Bocal Brush** are available for cleaning the insides of bassoon bocals. A special **Saxophone Neck Brush** includes a plastic covered flexible wire brush for cleaning inside saxophone necks.



Key Oil maintains smooth noiseless operation of key mechanisms. **Bore Oil** helps preserve the natural characteristics of the inner bore of wood instruments.



Mouthpiece Cleaner removes dirt and sanitizes the surface of the mouthpieces.

